

Software Manual Control Panel for Pegasus Units

Models: MD 421
MD 422



EN Software Manual 1-18

1. DESCRIPTION	3
2. DISPLAY LAYOUT	4
3. MODES	5
3.1 Power On	5
3.2 Standby	5
3.3 Power off	6
3.4 Error / Warning	6
4. CONTENT OF MAIN- AND SUBMENUS	7
5. OVERVIEW OF MAIN- AND SUB-MENUS	8
5.1 Content of the Info menu	9
5.2 Content of the Errors menu – CAUSE & REMEDY	9
5.2.1 Error List	9
5.3 Content of the Setup menu	11
5.3.1 Submenu setting	12
5.3.2 Submenu Language & Units	12
5.3.3 Submnenue Installation	12
5.4 Content of Readings	13
6. UPGRADE FIRMWARE	14
6.1 Upgrade using USB Cable	14
6.2 Upgrade using IrDA Cable	16
6.3 Upgrade Controller Board	18

1. Description

This software manual describes the operation of the control panel of the Single Booster unit. The unit is operated via the control panel (see below illustration).

1. OFF
Button (1) switches OFF the unit.
2. ON/STANDBY
Button (2) switches ON the unit.
3. ERROR
Error light indicator (3).
4. NAVIGATION BUTTONS
The four "arrow" navigation buttons (4) are used for navigation in the display menu. Pressing the "OK" button activates the menu and confirms any activity displayed.
5. DISPLAY



2. Display layout



(1)

When switched on the display will show an arrow symbol in the top right corner equivalent to the active navigation buttons on the control board.

The arrows illustrate that it is possible to scroll up and down between the menus. Scrolling to the right makes it possible to enter a value. Set the value scrolling up (+) or down (-) to set the value higher or lower accordingly. Confirm by pressing ok.


(2)

A letter combination for easy reference in connection with service work will appear in the top right corner of the display.


3. Modes

3.1 Power On

The very first time the unit is switched on, we recommend setting date and time in the Setup menu, settings, display EP. If date and time is not set, date and time will count from the pre-set default date and time.



Set date and time using navigation buttons.



Confirm by pressing OK button.

3.2 Standby

The start up display will look as the one below.



3.3 Power Off



When the unit is off the display will only show a small dot in the top right corner.

In Off mode it is possible to access all menus without the pump running by pressing the OK button on the panel.

Dot is equivalent to the OK confirm button on the panel.

3.4 Error/Warning



In case of an error, “ERROR” will appear on the display screen.

Press the OFF button to switch of unit.

If the error remains when the unit is switched ON again, please Press right arrow to see current error.

In case of a warning, “WARNING” will appear on the display screen. When a warning is detected the machine will either stop or run with limited performance until the cause of the warning has been improved (eg. inlet pressure).









To see further error/warning list and possible cause and remedy go to section 5.2.

4. Content of Main- and Submenus

The control panel contains the below main menu screen displays.

Scroll between the menus using the navigation buttons.

Each main menu contains submenus which will be described subsequently.

 Info	A	
 Errors	B	
 Setup	C	
 Readings	R	

5. Overview of Main- and Sub-menus

1. Info (A)

1 Info (AEA)

2. Errors (B)

3. Setup (C) (default password 6802)

1 Password (CA)

2 Settings (E)

Standard pressure (ER)

Auto off delay (EZ)

Date & Time (EP)

3 Languages & units (F)

Language (FA)

Units (FB)

4 Communication (I)

Get Errorlog by cable (IA)

Get errorlog by infrared (IB)

Firmware Upgrade by cable (IC)

Firmware Upgrade by infrared (ID)

5 Installation (K)

Install Password(KA)

6 Communication (I)

Get Errorlog by cable (IA)

Get Errorlog by infrared (IB)

Firmware Upgrade by cable (IC)

Firmware Upgrade by infrared (ID)

4. Readings (R)

Pump state (RA)

Pump-top pres. (RB)

Pump-top temp (RC)


Supply pressure (RD)

Supply temp. (RE)

Flow Status (RF)

5.1 Content of the Info menu

Please note that the Info menu is only for display – all data must be typed in via the setup menu!




This display view is only ment as an example, SW ID and CT ID shows the current SW version.

Displays Software version and Pump size, machine configuration and controller software version/ID.

5.2 Content of the Errors menu – CAUSE & REMEDY

Example of Error log screen display:

All error occurrences will be stamped with date and time.
E indicates Error number. P indicates Pump number.



The error log stores up to 1000 occurrences. When max. memory is reached, the errors will be deleted according to "First in" First out" principle.

5.2.1 Error List




Error	Cause	Remedy
C1 Inverter Error	1. Frequency inverter in error state	1. Switch off the power on the service switch. Wait 180 sec. Switch on the unit again. If error still occurs, please contact your Local service technician.
C2 Low Supply Pressure	1. Insufficient water supply	1. Secure sufficient water supply pressure. 2. Check inlet filter for impurities/rinse filter 3. Contact your Local service technician
C3 High Water Temp.	1. Water pump top temperature is above 80° 2. Water consumption is too low (pump column has been overheated)	1. Lower the inlet water temp. (max 70°C) 2. Secure sufficient water consumption 3. Contact your Local service technician
C4 High Motor Temp.	1. Insufficient cooling of motor 2. The ambient temperature is above 40°	1. Secure that all air channels are open and not blocked by impurities 2. Lower ambient temperature
C5 High Supply Temp.	1. Water inlet temperature is above 70°	1. Lower the water temp. (max 70°C) 2. Contact your Local service technician

C6 Low Sensor Supply Voltage	1. Voltage supply for sensors too low	1. Press "off" button 2. If error reoccurs, contact our Local service technician
C7 No Response Error	1. No communication between display and control board	1. Contact Local service technician
C8 Low Tank Level	1. Insufficient water supply 2. Water supply valve not open	1. Check correct water supply 2. Secure sufficient air supply to valve 3. Contact your Local service technician
C9 High Tank Level	1. Water supply valve not closed	1. Secure sufficient air supply to the valve. 2. Contact Local service technician
C11 Warning Cri. Inlet press.	1. Insufficient water supply 2. Booster will return to standby mode after 20 sec. If this error occurs 3 times within 20 min. Error C2 occurs.	1. Secure sufficient water supply or reduce consumption 2. Check inlet filter for impurities/rinse filter 3. Contact your Local service technician
C13 Warning Low inlet press.	1. Insufficient water supply. The machine will keep on working as always, but the maximum speed of the pump will be reduced until sufficient inlet pressure is present.	1. Secure sufficient water supply or reduce consumption 2. Check inlet filter for impurities/Rinse filter
C14 Warning leakage start	1. Booster start condition changed to flow, due to leakage in pipe	1. Check for leakage in pipe system. 2. Press "off" button 3. If error reoccurs, contact your Local service technician
C20 Low Sensor Signal P-Pump-top	1. Pressure signal from pumptop sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C21 Low Sensor Signal T-Pump-top	1. Temperature signal from pumptop, sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C22 Low Sensor Signal P-Inlet	1. Pressure signal from inlet sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C23 Low Sensor Signal T-Inlet	1. Temperature signal from inlet sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C24 Low Sensor Signal block	1. Signal from block sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C25 Low Sensor Signal flow	1. Signal from flow sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C30 High Sensor Signal P-Puump-top	1. Pressure signal from pumptop sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C31 High Sensor Signal T-Pump-top	1. Temperature signal from pumptop sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C32 High Sensor Signal P-Inlet	1. Pressure signal from inlet sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C33 High Sensor Signal T-Inlet	1. Temperature signal from inlet sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician




C34 High Sensor Signal block	1. Signal from block sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C35 High Sensor Signal flow	1. Signal from flow sensor, out of range	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C40 Sensor Load Pumptop Sensor	1. Supply voltage for pumpstop sensor too low. 2. Pumpstop sensor using too much current	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C41 Sensor Load Inlet sensor	1. Supply voltage for inlet sensor too low 2. Inlet sensor using too much current	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C42 Sensor Load Block sensor	1. Supply voltage for block sensor too low 2. Block sensor using too much current	1. Press "off" button 2. If error reoccurs, contact your Local service technician
C43 Sensor Load Flow sensor	1. Supply voltage for flow sensor too low 2. Flow sensor using too much current	1. Press "off" button 2. If error reoccurs, contact your Local service technician

5.3 Content of the Setup menu


The Setup Main menu contains the below submenus, which will be described subsequently.




Password Note: Default user password is 6802. Enter the settings menu to change the default password. To avoid unintended access to the system the Local service technician can insert a blocking preventing access to the password controlled menus.




5.3.1 Submenu setting



5.3.2 Submenu Language & Units






5.3.3 Submenu Installation




* For the use of authorised Local service technician only


5.4 Content of Readings


 Readings R 


Pump state RA 


Output frequency of
frequency inverter.

Pump-top pres.
24 bar RB 

Pump-top temp.
29°C RC 

Supply pressure
2.5 bar RD 

Supply temp.
29°C RE 

Flow status
No Flow RF 

6. Upgrade Firmware

Upgrading from software version 4.10 or higher

6.1 Upgrade using USB Cable


1. Connect USB cable (Item No. 110001526) to PC USB port (Remove other USB cables connected to PC)
2. Connect Display cable to USB cable
3. In the menu go to, Setup->"password"->Communication-> Firmware upgrade by cable->Confirm Firmware upgrade and press "OK"
4. Display should now be looking like this:

Upgrade Ready
Power Cycle and
Start PC App.


5. Disconnect display from usb cable and connect it again (Power cycle)
6. Make sure the Green "ON" led and the red "OFF" led at the display is both on, display is blank
7. Startup PC program FWU200.exe (can be downloaded from Nilfisk Food website)
8. Window should be looking like this




9. Press "Browse" button




10. Select the file you will use for upgrade. Software File can be downloaded from Nilfisk Food website. The name of the file should end with ".hex". Ex V4.14_SB_DISP.hex
11. When the file is located press "Open" in browser window
12. The file name will now be written in file text line




13. Press UPGRADE button in FWU 200 tool



14. After a short while the FWU tool should start upgrading, the upgrade button should turn Yellow and change to "RUNNING"



15. The progress bar "Program" must go to the end before the upgrade is complete (less than 1 minute)
16. When the upgrade is complete the FWU tool should be looking like this, Button turns Green and text changes to "DONE/NEW"



17. Now the display is upgraded
18. To verify software version in display, in the menu go to, Info->Machine info
19. Here you will find display software version and control software version. SW ID "Display software", HW ID "type of device", CT ID Controller board software(if display is not connected to a control board, control software will be 0/300)

6.2 Upgrade using IrDA Cable


1. Connect power to equipment
2. In the menu go to, Setup->"password"->Communication-> Firmware upgrade by Infrared->Confirm Firmware upgrade and press "OK"
3. Display should now be looking like this:

Upgrade Ready
Power Cycle and
Start PC App.


4. Turn Off equipment and turn it on again (Power cycle)
5. Make sure the All three led's are on (Green "ON", red "ERROR" and red "OFF") and the display is blank
6. Connect Irda module (Item No. 110001558) to PC USB port
7. Place Irda module on display module like this



8. Startup PC program FWU200.exe (can be downloaded from Nilfisk Food website)
9. Window should be looking like this




10. Press "Browse" button



11. Select the file you will use for upgrade. Software File can be downloaded from Nilfisk Food website. The name of the file should end with ".hex". Ex V4.14_SB_DISP.hex

12. When the file is located press “Open” in browser window
13. The file name will now be written in file text line




14. Press UPGRADE button in FWU 200 tool



15. After a short while the FWU tool should start upgrading, the upgrade button should turn Yellow and change to “RUNNING”




16. The progress bar “Program” must go to the end before the upgrade is complete (less than 1 minute)
17. When the upgrade is complete the FWU tool should be looking like this, Button turns Green and text changes to “DONE/NEW”



18. Now the display is upgraded
19. To verify software version in display, in the menu go to, Info->Machine info
20. Here you will find display software version and control software version. SW ID “Display software”, HW ID “type of device”, CT ID Controller board software(if display is not connected to a control board, control software will be 0/300)


6.3 Upgrade Controller Board

1. Make sure display is connected to controller
2. Power up equipment
3. In the menu go to, Setup->"password"->Communication-> Upgrade Controller->Confirm upgrade and press "OK"
4. Display will now look like this:




Upgrade Ready
Power Cycle and
wait for upgrade

5. Turn off power to equipment and turn it back on (Power cycle)
6. After power on display will look like this:




Upgrading
Erase 0%
Power Cycle
When Done!

7. When Erasing reaches 100%, the display will automatically start to program control board "Erase" is changed to "Program"



Upgrading
Program 0%
Power Cycle
When Done!

8. Program will now start to count from 0% to 100%
9. When program reaches 100%, the programming is complete
10. The display will be looking like this



Upgrading
Program 100%
Power Cycle
When Done!

11. Turn Off equipment and turn it on again (Power cycle)
12. Now the control PCB is upgraded
13. To verify software version in display, in the menu go to, Info->Machine info
14. Here you will find display software version and control software version. SW ID "Display software", HW ID "type of device", CT ID Controller board software

Printed in Denmark

No.: 110003649C June 2020

© 2014 All rights reserved
Distributor:

Nilfisk **FOOD**