

**Addendum for
MA/SA/MH & BF8
US certification-kit**


Addendum to Directions for use 110009190, 110009418 and 110009443 to cover item no. 110010025, 110010026 and 110010027 Complete US Certification-kit for SA/MA/MH and BF8.

General direction for use is found in Directions for use in the above-mentioned manuals.

Addendum is covering spare part list for the part that differ from a standard unit.

The motor circuit breaker is for protection of the motor only. We recommend NOT to set the motor circuit breaker otherwise than what is shown in the table on the next page.

All motor circuit breakers are adjusted to the recommended values from Nilfisk Food, so no further adjustments is necessary.



Pos. 1	110010018	Box for motor circuit breaker
Pos. 2	110010015	Motor circuit breaker 24-32A (for BF8)
Pos. 2	110010016	Motor circuit breaker 1-1,6A (for SA)
Pos. 2	110010017	Motor circuit breaker 13-18A (for MA & MH)
Pos 3	110010022	Motor circuit breaker complete for SA
Pos. 3	110010023	Motor circuit breaker complete for MA/MH
Pos. 3	110010024	Motor circuit breaker complete for BF8

Adjustment of current on the circuit breaker:



Use a screw driver to adjust the settings on the motor circuit breaker so that it fits to the current used by the unit (please see table below).

	Current (A)
SA – Automatic Satellite	1,0
MA/MH – Automatic Mainstation/Mainstation	14,2
BF8 - Booster	27,0

Diagram for motor circuit breaker

