

Hybrid/Pegasus Mainstation Service Check List

Location	Description	Action	6 months	12 Months	18 Months	24 Months
1	Inlet filter	Inspect and clean inlet filter	X	X	X	X
2	Flow switch	Inspect operation and adjust to 1 green light.	X	X	X	X
3	Water Non return valve	Inspect operation of NRV Replace		X	X	X
4	Pressure switch	Check O-ring condition top of sensor and check display for, supply pressure, pump top pressure and temperature.	X	X	X	X
5	Air non return valve	Check operation Replace complete NRV	X	X	X	X
6	Water Non return valve	Disassemble, inspect/ replace O-ring Replace complete NRV	X	X	X	X
7	Air valve	Inspect operation/ clean and lubricate piston Replace if required	X	X	X	X
8	Chemical Non return valve	Disassemble, inspect/ replace O-ring Replace complete NRV	X	X	X	X
9	Air non return valve	Disassemble and Inspect/ Replace O-ring Replace complete NRV	X	X	X	X
10	Injectors	Clean, Inspect/ Replace O-rings Replace	X	X	X	X
11	Selector switch Axel	Inspect O-rings/ Replace O-rings	X	X	X	X
12	Air regulator	Adjust pressure to ensure manometer operates and adjust to correct pressure.	X	X	X	X
	Faults read out	Inspect and record last 5 faults with dates.	X	X	X	X
	Chemical hoses	Replace chemical hoses		X		X

